

3.25"

**READ ME  
BEFORE TURNING ON YOUR CAMERA!**

**Answers to important Questions  
about your new Camcorder.**

**A few things you should know  
about your camcorder.....**

**1) Will this digital video camera work on my HDTV?**

- Yes, the HD1Z records in 720P HD and can be viewed on your High Definition TV. For HD viewing, You will need to connect the camera to your HDTV with a HDMI cable ( not included).

**2) Can I watch full 720P HD playback on my HD TV through the included AV Cable?**

- No. Full 720P HD playback on your television is only possible through an HDMI Cable (optional) and not through the supplied A/V cable. However, you can still view your videos in VGA mode with the supplied A/V cable.

**3) Does this Digital Video Camera take still pictures?**

- Yes. The camcorder is equipped with a secondary feature for capturing still photo images . The still camera feature is not meant to replace a still shot digital camera. It is only a side feature. The HD1Z's main purpose is that of a full motion video capture camcorder.

**4) Can I adjust the date and time on my Digital Video Camera?**

- Yes. If you wish for your files to be properly stamped

Continued on back →

5.5"

Front

3.25"

with the correct date and time, please refer to page 15 in the instruction manual to set the camcorder's calendar.

**5) Does this Digital Video Camera have digital zoom?**

- Yes, like most handheld pocket camcorders, the HD1Z has a digital zoom feature. Please note that digital zoom will degrade the quality of your images. As you zoom in, the picture tends to degrade and appear blurry – this is a normal occurrence for all products with digital zoom. Utilizing this feature may will degrade your HD recording to VGA quality. For best recording results, it's suggested to only use the optical capture mode.

**6) What is the purpose of the light on the front of the camcorder?**

- As an added bonus, the HD1Z is equipped with a built-in light. Press the Left key to turn this light on or off while you are in video or still photo mode as instructed in the Manual. This feature is only meant to increase the lighting within a close distance (no greater than two feet) from the subject being recorded. Please do not mistake this light for a flash as it does not serve the same purpose.

**Thank you for your purchase of the Sylvania  
HD1Z 720P Digital Video Camera.**

For more detailed information, please refer to the Instruction Manual and Quick Start Guide that are included in the box.

5.5"

Front